⟨Outdoor unit⟩ PAC-SH71DS-E

Mitsubishi Package Air-Conditioner Optional Component Instructions on Installing Drain Socket

SAFETY PRECAUTIONS

- •Read these "Safety Precautions" thoroughly and install the drain socket securely.
- •Be sure to observe the precautions given here: They are critical for safety.
- Precautions are classified using the following symbols depending on extent and type of danger by erroneous handling:

⚠WARNING Erroneous handling can cause death or serious injury. **⚠CAUTION** Erroneous handling can cause personal injury or damage

 After installation, make a trial run to ensure that no fault occurs, and ask the customer to keep this installation sheet with instruction manual. Also ask the customer to pass them to the new user if the user changes.

⚠ WARNING

Ask the dealer or specialist to install the drain socket.

•If the user install the drain socket incorrectly by yourself, some components could cause water leak, electric shock, fire, etc.

Securely install the drain socket, referring to this installation sheet.

 Incomplete installation could cause water leak, electric shock, fire, etc., with some components.

Before performing installation (moving) and electrical construction:

⚠ CAUTION

Do not place polyethylene bags in reach of children.

 Putting over the head will block breathing passages, which could result in suffocation.

If refrigerant piping is necessary, securely execute insulation so that condensation does not occur.

 Incomplete insulation will cause condensation on surface of pipe, etc and moisture will drip, which could wet ceiling, floor or other areas. If wiring for power supply is necessary, use only specified wires that comply with current capacity.

•Using other wires could cause leak, heat generation, fire, etc.

If drain piping is necessary, lay piping for secure drain, referring to instruction manual, and maintain the temperature to prevent condensation

 Incomplete piping will cause water leak, which could wet ceiling floor or household goods.

The outdoor unit is provided with several holes for drainage at the bottom to make drainage easier. The drain socket is used to close the unnecessary holes and centralize the drainage when using the drain tube at the installation place.

Do not to use the drain socket in cold areas. The drain tube can be frozen.

Condensation could drop through the part fitting holes and knockout holes (slits) in the bottom
 of the outdoor unit. Use the centralized drain pan to completely prevent condensation dropping.


1. Accessory


Be aware that the following parts are put in the package together with the instruction manual.

	0 1	•		0	9	
①Drain socket ········· 1 pc	②Drain cap					
	Large size: Small size:	·	0			
	%The numb	er of pieces	chan	ges dep	pending on the mode	∍l.
③Insulation part (for liquid pipe) · · · · 1 pc	4 Insulation part	(for gas pipe) ·····	1 pc	⑤Band	8 pcs	
Small size	\$	e Large s	size	,		

2. Installation method for drain unit ☆Prepare the adhesive in the field.

- (1) Glue the drain socket ① to the hole that is used to centralize the drainage among several holes at the bottom of the unit with the glue (Prepare in the field).
- (2) Glue the drain caps ② to close all the other unnecessary holes with the glue (Prepare in the field). The number of holes changes depending on the model.
 - Note Apply the glue securely, as the glue (Prepare in the field) will work as seal to prevent water from leaking.
 - (Note) Use the adhesive for the rubber and metal.
- (3) Insert a vinyl tube of which inner diameter 25 mm available commercially or a hard vinyl tube VP25 to the drain socket ①.





For outdoor unit with a dimension of 800×600×300 (width×height×depth)

3. Installation method for insulation parts

Install the insulation parts to stop valve of the outdoor unit.

- *The insulation parts should be installed after the tube has been connected to the unit.
- *Some units are provided with a check valve near stop valve. In this case,
- cut the insulation parts 3 and 4 so that they will fit the stop valve properly.
- (1) Install the insulation part ③ with 2 holes to the liquid pipe side so that the holes fit the valve caps and cover the stop valve entirely.
- (2) Fix the insulation part ③ securely with bands ⑤. Install the other insulation part ④ to the gas pipe side with the same procedure.

