Photo



Descriptions

Enables operation even when the outside temperature is low. Protect the unit from cold wind.

pplicable Models

PUHZ-P100/125/140/200/250KA


2 pieces required


Specification

Exterior	Color (Munsell)	Ivory (3.0Y 7.8/1.1)			
	Surface treatment	Acrylic resin coating			
	Material	Alloy hot-dip zinc-coated carbon stee sheet			
Weight		3.5kg			
Accessory name x Qty. <material surface="" treatment=""></material>		Washer faced screw (M5x15) x 4 <iron (swch18a)="" nickel<br="" wire="" zinc="">plated></iron>			

Dimensions

Unit: mm (inch)





⚠ CAUTION


* Air Guide prevents reverse rotation of outdoor unit fan when it enters low speed rotation mode with fan controller being operated. It is also used for protection of fan when strong winds, such as a typhoon, wind blowing through tall buildings, etc., directly strike the air outlet. In addition, installation of this product is necessary when cooling operation is to be performed in outdoor tempreture of -5°C or lower (down to -15°C).

- Note the followings when installing this guide:

 1) Be sure not to use "upward discharge" in a place where snowing is possible. Snow may accumulate in the guard, which could damage the fan, etc.

 2) Attaching this unit will decrease the performance (by 2-3%) and increase noise from outdoor unit (by approx. 1-2 dB).
- Do not use "upward discharge" when there are any obstacles at the back and on both sides of outdoor unit (air is taken in from top of unit): This could cause a short cycle.
 To eliminate the influence of external wind, be sure to install the unit with its back facing to wall.
- 5) Do not install this unit in a place where wind directly blows to the back of the unit.

How to Use / How to Install



This Air Guide prevents reverse rotation of outdoor unit fan when it enters low speed rotation mode with fan controller being operated. It is also used for protection of fan when strong winds, such as in a typhoon, wind blowing through tall buildings, etc., directly strike the at air outlet.

In addition, installation of this product is necessary when cooling operation is to be performed in outside-air temperature of -5°C or lower (down to -15°C).

Pay attention to the following points when installing this product:

- 1) To eliminate the effects of external wind, be sure to install this unit with back surface facing wall side.
- 2) Do not install this unit in orientation or site where wind directly blows at the back of the unit.
- 3) Installing of this product will reduce the capacity of the unit (approx. 2 or 3%) and increase the noise of outdoor unit (approx. 1 or 2dB).
- 4) Do not use this product where there is any obstacle at either side or above the outdoor unit (discharged air will be blocked). This may cause a short cycle.

When 2-fan type outdoor unit is used, note that two sets of this product will be becessary.

1 | Checking parts


Make sure that all the following parts, in addition to this manual, are in this box:

①Air Guide	1	②Mounting screw (5×15)	6	3Washer	6	6


(Unit: mm)

2 Requirements of space for installation

(1)One unit installation



(2) Multiple unit installation: Installation of multiple units in series must be no more than 5 units.



3 Installation procedure

(1)Install the air guide \odot on the outdoor unit using washers \odot , spring washers \odot and screws \odot .

