



# Settings and pump curves Laddomat LMXA

## Einstellungen der LADDOMAT<sup>®</sup> Hocheffizienzpumpen



Recommended speed for all Laddomats  
Standard mit Laddomat

	Laddomat LM4A		Laddomat LM6A		Laddomat LM8A	
I	5-25 W	8 W	7-50 W	16 W	7-75 W	26 W
II	7-25 W	17 W	10-50 W	34 W	12-75 W	52 W
III	10-25 W	25 W	12-50 W	50 W	16-75 W	75 W



230 V ± 10 %, 50 Hz

# LADDOMAT<sup>®</sup>



by Termoventiler AB

Hersteller: +46 (0)321 - 26180 • info@termoventiler.se • www.laddomat.eu  
Tochtergesellschaft: 03722 505700 • info@termoventiler.de • www.laddomat.de

## None regulated pump curves Laddomat LM-4A Ungeregelte Betriebsart Laddomat LM-4A



## None regulated pump curves Laddomat LM-6A Ungeregelte Betriebsart Laddomat LM-6A



## None regulated pump curves Laddomat LM-8A Ungeregelte Betriebsart Laddomat LM-8A

